



MACINTOSH EXTERNAL DRIVE TECHNICAL PROCEDURES

TABLE OF CONTENTS

Section 1. Take-apart

Remove and Replace the External Drive.....1.3

Section 2. Illustrated Parts List

Illustrated Parts List and Diagram.....2.1

©Apple Computer, Inc., 1985.

No part of this document may be reproduced in any form
without the written permission of Apple Computer, Inc.

Apple and the Apple logo are registered trademarks of
Apple Computer, Inc.



Macintosh External Drive Technical Procedures

Section 1

Take-apart

Contents:

Remove and Replace the External Drive.....1.3

©Apple Computer, Inc., 1985.

No part of this document may be reproduced in any form without the written permission of Apple Computer, Inc.

Apple and the Apple logo are registered trademarks of Apple Computer, Inc.




FIGURE 1



Remove and Replace the External Disk Drive:

Equipment Required:

#1 Phillips screwdriver

1. Turn the disk drive over with the bottom facing up.
2. Remove the six screws and washers from the bottom cover.
NOTE: The two black screws do not have washers.
3. Lift up the back of the bottom cover about an inch and pull it out from the front bezel.
4. Lift up the cable grommet (see Figure 1, #1) from the case and support it with one hand; with the other hand lift up the back of the metal drive housing and remove the drive from the bottom cover.
5. Carefully remove the cable connector and ground braid from the disk drive (see Figure 1, #2).
6. Remove the screw on the outside of the metal drive housing (see Figure 1, #3).
7. Slide the drive out of the metal housing.

Replace:

1. Connect the drive cable and ground braid to the new drive (see Figure 1, #2).
2. Place the new drive into the metal housing and replace the screw (see Figure 1, #3).
3. Place the drive into the bottom cover at an angle and support the cable assembly while you push the drive forward.
4. Replace the cable grommet in its slot.
5. Replace the top cover and screws.



Macintosh External Drive Technical Procedures

Section 2

Illustrated Parts List


Contents:

| | |
|---|-----|
| Illustrated Parts List and Diagram..... | 2.1 |
|---|-----|

©Apple Computer, Inc., 1985.

No part of this document may be reproduced in any form without the written permission of Apple Computer, Inc.

Apple and the Apple logo are registered trademarks of Apple Computer, Inc.





MACINTOSH EXTERNAL DRIVE (Figure 6)

| Item | Part No. | Description |
|-------------|-----------------|---------------------------------------|
| 1 | 815-0796 | Cover, Upper Macintosh External Drive |
| 2 | 661-76156 | Micro Disk Assembly |
| 3 | 815-0795 | Cover, Lower Macintosh External Drive |
| 4 | 424-1001 | Screw, Tap M2.9x1.06x13 |
| 5 | 467-3000 | Screw, M3.5x10 |
| 6 | 865-0011 | Foot, Macintosh |
| 7 | 590-0183 | Macintosh External Drive Cable |

